

# Digital Battery Meter


## Microcat "HD"

Thank you for purchasing this advanced meter. Please take a few moments to read these operating instructions.

### Overview:

The purpose of the meter is to indicate the number of minutes of usable life left in the batteries on the **Microcat "HD"**.

It uses a sophisticated computer program to test the battery(s) and discover how much running time is left.



### Operation:

1. Plug the meter into the gold charging socket, with the boat switched "off".
2. Wait for approximately 25-30 seconds, while the line goes around in square. Then the number displayed indicates the number of minutes available.
3. Unplug the meter.

### Notes:

- a. The meter will become warm during operation - This is normal.
- b. **Always disconnect** the meter immediately after taking a reading.
- c. The readings relate to the Microcat "HD" using the Heavy Duty batteries (12Ah).
- d. A reading of above 99 minutes will display "Hi".
- e. A reading of "Lo" means there is less than 7 minutes running time left in the battery(s)
- f. The meter is splash proof.
- g. The meter will not give meaningful readings on non Angling Technics boats.