

Digital Battery Meter

Technicat

Thank you for purchasing this advanced meter. Please take a few moments to read these operating instructions.

Overview:

The purpose of the meter is to indicate the number of minutes of usable life left in the batteries on the Technicat.

It uses a sophisticated computer program to test the battery(s) and discover how much running time is left.



Operation:

1. Plug the meter into the gold charging socket, with the boat switched "off".
2. Wait for approximately 25-30 seconds, while the line goes around in square. Then the number displayed indicates the number of minutes available.
3. Unplug the meter.

Notes:

- a. The meter will become warm during operation - This is normal.
- b. **Always disconnect** the meter immediately after taking a reading.
- c. The readings relate to the Technicat using the standard 7Ah batteries.
- d. Add 30% to the reading if using the Heavy Duty (12Ah) batteries in the Technicat.
- e. A reading of above 90 minutes will display "Hi".
- f. A reading of "Lo" means there is less than 7 minutes running time left in the battery(s)
- g. The meter is splash proof.
- h. The meter will not give meaningful readings on non Angling Technics boats.